




1500 AND 2500 SERIES SINGLE AGE END C

IN ALLA ION, OPERA ION AND MAIN ENAM

NOTE! To the installer: Please make sure you provide this manual to the owner or the party who maintains the system.

Part #FM-03-525 | © 2012 Pentair Ltd. | 12/21/12



MODELS 1500 AND 2500

—

GROUTING THE INSTALLATION:

Grouting the base plate prevents lateral movement of the base plate and improves the vibration absorbing characteristics of the foundation by increasing its mass. A wooden dam should be constructed around the base plate to contain the grout while it is being poured. The dam can either be built tight against the base plate, or slightly removed from it as desired. (See Fig. 2.) The entire base plate should be completely filled with non-shrinkable type grout. The grout should be puddled frequently to remove any air bubbles.

ROTATION:

Pump rotation is clockwise when viewed from the back of the motor. An arrow is also located on the pump to show the direction of rotation.

WARNING: Sudden Start-up Hazard

Disconnect and lock out power source before servicing. Failure to follow these instructions could result in serious personal injury, death or property damage.

INITIAL ALIGNMENT OF THE FLEXIBLE COUPLING:

To check parallel alignment, hold a straight edge against the edges of the coupling halves at any four places 90° apart around the coupling. The straight edge should be parallel to the pump and driver shafts at all times. Insert shims until the straight edge lies flat against both coupling halves at all four checkpoints. The pump and driver will then be in proper parallel alignment. (See Fig. 3.)

PIPE:

The discharge pipe diameter should be the same as, or larger than, the discharge nozzle diameter.

DISCHARGE VALVES:

The discharge piping should include a check valve and a gate valve. The check valve should be located between the gate valve and the pump. If an increaser is used in the discharge piping, the increaser should be installed between the pump nozzle and the check valve. The check valve protects against a reverse flow of the liquid if the driver fails. (See Fig. 5.)

The gate valve is used in the priming operation as a throttling valve to control pump

MODELS 1500 AND 2500 OPERATION INSTRUCTIONS

Centrifugal pumps operate under a wide range of conditions. The pump you have selected exactly fits your specific requirements. Before putting your pump into operation, however, there are certain basic ground rules that must be followed to assure maximum efficiency, long pump life, and maintenance-free service.

Centrifugal pumps should never be started or run dry. Operating a pump dry can cause burning of the packings or seal, resulting in destruction of the packings or seals, and possible scoring of the pump shaft. To prevent the pump from being run dry, the pump should be primed before starting it.

A centrifugal pump should not be throttled, or the volume controlled on the suction side of the pump. Throttling the pump on the suction side not only reduces the capacity, but also reduces pump efficiency and, more importantly, can cause serious damage to the pump due to cavitation. Cavitation occurs when the pressure at any point inside the pump drops below the vapor pressure of the liquid. The liquid flashes and forms vapor bubbles. These bubbles move along with the liquid into a higher pressure area, where the bubbles collapse or implode, creating an area of low pressure. The implosion phenomenon is characterized by a crackling noise and sometimes by loud knocking as the vapor bubbles are collapsed. Repetition of this action causes a wearing away of the metal on the impeller and other parts of the pump, and if allowed to continue can result in serious damage to the pump.

Pump capacity can be effectively controlled by use of a throttling valve in the discharge piping. Most centrifugal pumps can be operated for brief periods of time with the throttling valve closed without building up excessive pressure or overloading the drive unit. In fact, a centrifugal pump operating against a closed discharge line at its rated capacity actually requires less power to operate than it does when the throttling valve is open.

The pump should never be started with the throttling valve completely closed, however, because a condition of water hammer could exist. The condition of water hammer is caused by an increase in pressure due to changes in velocity of the liquid flowing through the pipe line. When the velocity is changed by closing a valve or by some other means, the magnitude of the pressure produced is frequently much greater than the static pressure on the line, and may cause rupture or damage to the pump, piping, or fittings. Water hammer may be controlled by regulating valve closure or by the use of relief valves and slow-closing check valves.

On pumps equipped with packings, there should be sufficient leakage from the packing to ensure lubrication of the packing and effective cooling of the stuffing box. The packing glands should always be adjusted evenly and not too

with the pump so that the drive shaft may deflect, causing a misalignment of the pump and the drive. J/T1 1 T/12 00 12 55 180.77

AIR EJECTOR:

One type of vacuum primer is the air ejector. If liquid under pressure, or steam, is available, an ejector can be used. The ejector is connected to the air vent orifice. A stream of the ejecting medium is passed through the ejector, creating a vacuum in the ejector and drawing air from the pump casing and suction piping. When liquid flows steadily from the ejector discharge pipe, the pump is primed.

POSITION OF SUCTION PIPING GATE VALVE:

In flooded suction applications, the gate valve is opened when the pump is being primed and will remain open for starting and operation.

COOLANT VALVES:

Valves in the cooling liquid line should be opened prior to starting the pump, and should remain open while the pump is in operation unless it is desirable to check the rate of leakage from the stuffing box.

SHUTTING DOWN THE PUMP:

To shut down your pump, simply close the discharge gate valve and shut down the motor. If it is necessary for the pump to maintain its prime while it is shut down, it is advisable to install either a foot valve or a check valve in the suction piping.




Fig. 13 Inductor Priming.

running time or every 4–6 months, whichever is more frequent. A unit is considered to be installed in a wet location if the pump and motor are exposed to dripping water, to the weather, or to heavy condensation such as is found in unheated and poorly ventilated underground locations.

Oil lubricated bearings are optional on Model 1520/2520 pumps. A fixed oil level is maintained with the power frame by an oiler which allows visual indications of reserve oil. At initial installation and before starting a unit that has been shut down for repairs or for any extended length of time, run enough 10W-30 weight motor oil through the oiler to maintain a constant oil level to ensure that the bearing will never be without an oil supply. Oil will have to be added at intervals to maintain a constant level in the oiler. This interval can be determined only by experience.

Under working conditions, oil will break down and need to be replaced at regular intervals. The length of these intervals will depend on many factors. Under normal operation, in clean and dry locations, the oil should be changed about once a year; however, when the pump is exposed to dirt contamination, high temperatures (200°F or above) or a wet location, the oil may have to be changed every 2–3 months.

CAUTION:

Use normal fire caution procedures when using any petroleum cleaner.

The motor that drives your Fairbanks Nijhuis pump may or may not require lubrication. Consult the manufacturer's recommendations for proper maintenance instructions.

REPAIRS:

Before starting any work, ensure the electrical power is locked out, the system pressure has been lowered to 0 psi and temperature of the unit is at a safe level.

The pump may be disassembled using the illustrations and text provided. Although complete disassembly is covered, it will seldom be necessary to completely disassemble your Fairbanks Nijhuis pump.

The illustrations accompanying the disassembly instructions show the pump at various stages of disassembly. The illustrations are intended to aid in the correct identification of the parts mentioned in the text.

Inspect removed parts at disassembly to determine if they can be reused. Ball bearings that turn roughly or show wear should be replaced. Cracked castings should never be reused. Scored or worn pump shafts should be replaced. Gaskets should be replaced at reassembly simply as a matter of economy. They are much less expensive to replace routinely than to replace singly as the need arises.

WARNING: Sudden Start-Up Hazard

Disconnect and lock out power source before servicing. Failure to follow these instructions could result in serious personal injury, death or property damage.

WARNING: Hot Surface Hazard

If pumping hot water, ensure guards or proper insulation is installed to protect against skin contact to hot piping or pump components. Failure to follow these instructions could result in serious personal injury, death or property damage.

WARNING: High Pressure Hazard

- C. Slide sleeve (25) with rotating parts of mechanical seal (27) from the shaft. The sleeve should be carefully cleaned to remove any residue that may remain in the seal area. The rubber in the seal may have partially adhered to the sleeve. The sleeve must also be checked for abrasion or corrosion that can occur when fluid residue penetrates between the seal (27) and sleeve (25). The sleeve under the seal may be polished lightly to a 32RMS finish before reassembly. Do not reuse a pitted sleeve. Pin (61) maybe removed from the sleeve (25) if necessary.
 - D. Remove gland (23) and gasket (66).
 - E. The seal flexible cup and stationary seat should be pressed out of the gland (23) and the cavity cleaned of all residue. Make sure that the 1/32" radius in the seal seat cavity is not damaged during disassembly since a sharp edge can easily cut the flexible cup during reassembly.
- 10b. For Models 2550, 2530, 2520: Slide sleeve (25) with rotating parts of mechanical seal (27) from the shaft. The sleeve should be carefully cleaned to remove any residue that may remain in the seal area. The rubber in seal (27) may have partially adhered to the sleeve. The sleeve must also be checked for abrasion or corrosion that can occur when fluid residue penetrates between the seal (27) and sleeve (25). The sleeve under the seal may be polished lightly to a 32 RMS finish before reassembly. Do not reuse a pitted sleeve. Pin (61) may be removed if necessary.

CAUTION:

The mechanical seal (see Figure 25) is a precision product and must be treated as such. During removal, great care must be taken to avoid dropping any part of the seal. Take particular care not to scratch the lapped faces on the washer or the sealing seat. If any wear of the seal faces is noted, it is recommended to replace with a new seal during reassembly.

11.

14. For Models 2550, 2530, 2520: The seal flexible cup and stationary seat should be pressed out of the bracket (35) and the cavity cleaned of all residue. Make sure that the 1/32" radius in the seal seat cavity is not damaged during disassembly since a sharp edge can easily cut the flexible cup during reassembly.
15. Remove key (42) from the shaft and remove slingers (47). (1520/2520)
- 16.

capscrews should be either loosened or tightened one quarter turn at a time to acquire the correct leakage (both nuts or capscrews must be turned equally to prevent cocking of the gland). It will take approximately ten minutes at any one gland setting before the leakage rate will stabilize. When in doubt, choose the greater leakage rate since overly tight packing will ruin not only the packing, but the sleeve as well.

MECHANICAL SEAL (OPTIONAL):

The mechanical seal (27) (see Figure 25), should not be installed as an assembly. It is necessary to have the seal seat properly in place before the balance of parts can be added.

- A. Wipe the sealing faces of the seat and seal washer clean. Apply a film of liquid dishwashing detergent (do not use oil or grease) to the flexible bellows in the rotating assembly and shaft sleeve (25). Slide the entire rotating assembly onto the sleeve, making sure that the carbon washer faces away from the step in the sleeve.
- B. Thoroughly inspect the gland (23), checking for burrs or nicks which could damage flexible cup of mechanical seal. Apply a film of liquid dishwashing detergent (do not use oil or grease) to the flexible cup. Insert seat in cup and install in gland (23). NOTE: If it is not possible to insert seat with fingers, place cardboard protecting ring furnished with seal overlapped face of seat and press into place with a piece of tubing having end cut square. The tubing should be slightly larger than the diameter of the shaft. Remove cardboard after seat is firmly in place. Carefully slip the seal gland assembly (23) over the shaft with the stationary seat facing away from the motor. Insert gasket (66) over shaft.
- C. The shaft sleeve with the seal rotating assembly on it may now be replaced on the shaft. Carefully slide the seal gland (23) and gasket (66) onto the sleeve before seating the sleeve (25) against the shaft shoulder.
- D. Carefully slip cover assembly (26) over the shaft into its original position and secure with either capscrews (20 or 5).
- E. Position seal gland (23) and gasket (66) onto the cover (26) taking care to seat it evenly and squarely. Secure by tightening capscrews (65) evenly. Spring tension will probably prevent the sleeve from remaining in position axially until impeller is installed.

READ BEFORE INITIAL STARTING OR STARTING AFTER REASSEMBLY

STARTING PUMP AFTER REASSEMBLY:

Do not start pump until all air and vapor has been bled and until making sure that there is liquid in the pump to provide the necessary lubrication. Without the fluid around it, the seal may be ruined in a few seconds of operation. It is possible that the mechanical seal may drip during the first few minutes to one hour of operation.

WARNING: Hot Surface Hazard

If pumping hot water, ensure guards or proper insulation is installed to protect against skin contact to hot piping or pump components. Failure to follow these instructions could result in serious personal injury, death or property damage.

WARNING: Spraying Water Hazard

When servicing pump replace all gaskets and seals. Do not reuse old gaskets or seals. Failure to follow these instructions could result in serious personal injury, death or property damage.

WARNING: Electrical Shock Hazard

All electrical connections are to be made by a qualified electrician in accordance with all codes and ordinances. Failure to follow these instructions could result in serious personal injury, death or property damage.

WARNING: Electrical Overload Hazard

Ensure all motors have properly sized overload protection. Failure to follow these instructions could result in serious personal injury, death or property damage.

WARNING: Sudden Start-Up Hazard

Disconnect and lock out power source before servicing. Failure to follow these instructions could result in serious personal injury, death or property damage.

WARNING:

On the 1520 with a 15" impeller on a #21 power frame, reverse rotation will destroy the pump.

You must make sure that the motor rotates in the proper direction BEFORE coupling the motor to the pump. Start the drive motor to make sure the direction of rotation is the same as the direction indicated by the arrow on the pump casing.

The arrow on the casing always points clockwise when the pump is viewed from the motor end.

On 3 phase motors, you can reverse one of the power leads if the motor is not rotating clockwise.

WARNING:

Reverse rotation will quickly destroy the pump.

After you are sure the motor is rotating clockwise you can couple the motor to the pump. Again, after coupling but BEFORE starting it is important to check coupling and shaft alignment. Use a standard dial indicator to align the motor shaft and pump shaft to within 0.003"–0.005".

Model 1550 List of Parts

1. Elbow	9B. Gasket	19. Gasket	27. Seal
2. Connector	9C. Capscrew Seal	19A. Gasket	28. Packing
3. Tubing	10. Gasket	20. Capscrew	29. Lantern Ring
4. Plug, Pipe	11. Impeller	(not shown)	32. Capscrew
5. Capscrew	12. Impeller Key	21. Nut	33. Screw
6. Casing	14. Wear Ring	22. Clamp	34. Nameplate
7. Wear Ring	15. Wear Ring	23. Gland	35. Bracket
8. Gasket	16. Wear Ring	24. Stud	39. Capscrew
9. Impeller Screw	17. Retaining Ring	25. Sleeve	
9A. Washer	18. Jacket	26. Cover	

Model 1530 List of Parts

1. Elbow	11. Impeller	23. Gland	65. Capscrew
2. Connector	12. Impeller Key	24. Stud	66. Gasket
3. Tubing	14. Wear Ring	25. Sleeve	67. Plug, Pipe
4. Plug, Pipe	15. Wear Ring	26. Cover	68. Plug, Pipe
5. Capscrew	16. Wear Ring	27. Seal	69. Nipple
6. Casing	17. Retaining Ring	28. Packing	70. Gasket
7. Wear Ring	18. Jacket	29. Lantern Ring	71. Locknut
8. Gasket	19. Gasket	32. Capscrew	72. Gasket
9. Impeller Screw	19A. Gasket	33. Screw	73. Base
9A. Washer	20. Capscrew	34. Nameplate	74. Plug, Pipe
9B. Gasket	(not shown)	35. Bracket	75. Plug, Pipe
9C. Capscrew Seal	21. Nut	39. Capscrew	76. Coupling, Pipe
10. Gasket	22. Clamp	61. Pin	

Model 1520 List of Parts

1. Elbow	17. Retaining Ring	35. Bracket	55. Shaft
2. Connector	18. Jacket	39. Capscrew	56. Plug, Pipe
3. Tubing	19. Gasket	40. Washer	57. Frame
4. Plug, Pipe	19A. Gasket	41. Support	58. Grease Fitting
5. Capscrew	20. Capscrew	42. Key	59. Plug, Pipe
6. Casing	(not shown)	43. Grease Fitting	60. Oiler Assembly
7. Wear Ring	21. Nut	44. Tube, Vent	61. Pin
8. Gasket	22. Clamp	46. Plug, Pipe	62. Capscrew
9. Impeller Screw	23. Gland	47. Slinger	63. Washer
9A. Washer	24. Stud	47A. Slinger	64. Support
9B. Gasket	25. Sleeve	48. Capscrew	65. Capscrew
9C. Capscrew Seal	26. Cover	49. Bearing Cap	66. Gasket
10. Gasket	27. Seal	50. Gasket	67. Plug, Pipe
11. Impeller	28. Packing	51. Seal	68. Plug, Pipe
12. Impeller Key	29. Lantern Ring	51A. Seal	69. Nipple
14. Wear Ring	32. Capscrew	52. Retaining Ring	70. Gasket
15. Wear Ring	33. Screw	53. Bearing	71. Locknut
16. Wear Ring	34. Nameplate	54. Bearing	76.



Model 2550 List of Parts


1. Elbow	8. Gasket	12. Impeller Key	33. Screw
2. Connector	9. Impeller Screw	14. Wear Ring	34. Nameplate
3. Tubing	9A. Washer	15. Wear Ring	35. Bracket
4. Plug, Pipe	9B. Gasket	16. Wear Ring	39. Capscrew
5. Capscrew	9C. Capscrew Seal	25. Sleeve	40. Washer
6. Casing	10. Gasket	27. Seal	41. Support
7. Wear Ring	11. Impeller	32. Capscrew	61. Pin


Model 2530 List of Parts

1. Elbow	9. Impeller Screw	15. Wear Ring	39. Capscrew
2. Connector	9A. Washer	16. Wear Ring	61. Pin
3. Tubing	9B. Gasket	25. Sleeve	72. Gasket
4. Plug, Pipe	9C. Capscrew Seal	27. Seal	73. Base
5. Capscrew	10. Gasket	32. Capscrew	74. Plug, Pipe
6. Casing	11. Impeller	33. Screw	75. Plug, Pipe
7. Wear Ring	12. Impeller Key	34. Nameplate	
8. Gasket	14. Wear Ring	35. Bracket	

Model 2520 List of Parts

1. Elbow	11. Impeller	41. Support
2. Connector	12. Impeller Key	42. Key
3. Tubing	14. Wear Ring	43. Grease Fitting
4. Plug, Pipe	15. Wear Ring	44. Tube, Vent
5. Capscrew	16. Wear Ring	46. Plug, Pipe
6. Casing	25. Sleeve	47. Slinger
7. Wear Ring	27. Seal	47A. Slinger
8. Gasket	32. Capscrew	48. Capscrew
9. Impeller Screw	33. Screw	49. Bearing Cap
9A. Washer	34. Nameplate	50. O-g
9B. Gasket	35. Bracket	
9C. Capscrew Seal	39. Capscrew	
10. Gasket	40. Washer	





HP PAGE IN EN IONALL LEF BLANK