SYSTEM DESCRIPTION

Leveraging proprietary technology, the EZ-RO 375/16ATM-BL system uses Reverse Osmosis (RO) to reduce Total Dissolved Solids (TDS); it provides up to 375 gal/day (1,419 L/day)* and includes a 16-gallon (60.6 L) atmospheric tank. Blending and remineralization allow you to control TDS for optimal espresso, coffee and tea*.

APPLICATIONS

Espresso Coffee Tea / iced tea Ice

FEATURES • BENEFITS

Meets espresso, coffee, and tea equipment and customer water quality standards; known to signif cantly reduce scale and corrosion problems due to high TDS, water hardness*, and chlorides†

Precision stainless steel blend valve and built-in TDS meter allow customized TDS for optimum extraction and taste prof le for espresso, coffee and tea*

4CM cartridge provides calcium and magnesium for improved extraction

Sealed atmospheric storage tank provides compact capacity and electronic pump delivers optimized water to downstream equipment

Pressure gauge allows monitoring of RO inlet pressure and pref Iter condition



